



Insignia NS-B2110 Antenna Replacement

This guide will show you how to replace the antenna of the Insignia NS-B2110.

Written By: Daniel Hodges



INTRODUCTION

The antenna is a very important component for the radio of the Insignia NS-B2110. Antennas may snap or break, causing the radio to stop working. Removing the antenna is a fairly easy and quick fix.



TOOLS:


- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Antenna



- On the backside of the device, lift the plastic handle up with your hands to reveal the antenna.
- Lift the antenna to its upright position.

Step 2



- Remove one 6.0 mm Phillips #00 screw from the base of the antenna.
- Remove the antenna from the metal bracket.

To reassemble your device, follow these instructions in reverse order.

